CROWN POINT

SCALE:-1 INCH=100 FEET

Note:- All returns and curve points set with 1 inch iron pipe.
All lot corners set with 2x2 redwood hubs.
Bearings based on solar observation.